



Photoelectric Sensor Convergent Mode Sensor Q45AD9CVQ




Туре	Q45AD9CVQ	
ID	3037633	
Optical data		
Function	Proximity switch	
Operating mode	Convergent	
Light type	Red	
Wavelength	680 nm	
Focal distance	38 mm	
Electrical data		
Operating voltage U _B	515 VDC	
Voltage	Nom. 8.2 VDC	
Current consumption non-actuated	≤ 1 mA	
Actuated current consumption	≥ 2.1 mA	
No-load current I _o	≤ 2.1 mA	
Output function	Light operation, NAMUR	
Switching frequency	≤ 100 Hz	
Readiness delay	≤ 0 ms	
Response time typical	< 5 ms	
Setting option	Potentiometer	
Ma ala asia al alata		
Mechanical data	Destauration OAS	
Design	Rectangular, Q45	
Dimensions	Ø 30 x 56.4 x 44.5 x 102.6 mm	
Housing material	Plastic, Thermoplastic material	
Lens	plastic, Acrylic	
Electrical connection	Connector, M12 × 1, PVC	
Number of cores	4	
Ambient temperature	-40+70 °C	
Protection class	IP67	
Switching state	LED, Red	
Excess gain indication	LED, flashing	

- Male M12 × 1
- Protection class IP67
- Sensitivity adjusted via potentiometer
- Operating voltage: 5...15 VDC
- NAMUR output: dark <= 1.2 mA; light >= 2.1 mA
- Acc. to EN 60947-5-6 (NAMUR)
- ATEX category II 1 G, Ex zone 0

Wiring Diagram





Functional principle


Convergent mode sensors are equipped with a lens in front of the emitter diode that produces a small and intense focal point at a defined distance from the sensor. Similar to diffuse mode sensors, the light reflected by the target is evaluated. Convergent mode sensors are ideal for detection of small targets or colour marks and edge guiding or positioning control of transparent materials. The targets must always be within the focal depth of the sensors. The focal depth is defined as the area in front of or behind the focal point within which the object can be detected. Based on the intense light concentration in the focal point, convergent mode sensors are capable of detecting targets with a low reflectivity.

Excess gain curve

Excess gain in relation to the distance



Tests/approvals	
MTTF	67 years acc. to SN 29500 (Ed. 99) 40 °C
Approvals	CE, FM, CSA
Approvals	ATEX II 1 G
	ATEX II 2 G
	ATEX II 3 G
Device marking	EX II 1 G Ex ia IIC T5 Ga
Ignition protection category	Ex ia IIC T5
Ex approval acc. to conformity certificate	FM12ATEX0094X





Accessories

Type code	Ident no.		Dimension drawing
SMB30A	3032723	Mounting bracket, rectangular, stainless steel, for sensors with 30mm thread	o 30,5 6,3 wide o 6,3 R 40 69
SMB30FAM10	3011185	Mounting bracket, stainless steel, for M10 x 1.5 thread, thread length 30 mm	78.4 60.3 19 0 30.1 M10
SMB30SC	3052521	Mounting bracket, PBT black, for sensors with 30 mm thread rotatable	12.7 M30 x 1,5 97 50,8 29

Function accessories

Type code	Ident no.		Dimension drawing
IM1-22EX-R	7541231	Isolating switching amplifier, 2-channel; 2 relay outputs; input NAMUR signal; selectable ON/OFF mode for wire-break and short-circuit monitoring; adjustable output mode (NO / NC mode); removable terminal blocks; width 18 mm; universal power supply unit	104



Operating manual

Intended use

This device fulfills the directive 94/9/EC and is suited for use in explosion hazardous areas according to EN60079-0:2009, -11:2012, -26:2007. In order to ensure correct operation to the intended purpose it is required to observe the national regulations and directives.

For use in explosion hazardous areas conform to classification

II 1 G (Group II, Category 1 G, electrical equipment for gaseous atmospheres).

Marking (see device or technical data sheet)

ⓑ II 1 G and Ex ia IIC T5 Ga acc. to EN60079-0, -11 and -26

Local admissible ambient temperature

-25...+70 °C

Installation/Commissioning

These devices may only be installed, connected and operated by trained and qualified staff. Qualified staff must have knowledge of protection classes, directives and regulations concerning electrical equipment designed for use in explosion hazardous areas.

Please verify that the classification and the marking on the device comply with the actual application conditions.

This device is only suited for connection to approved Exi circuits according to EN 60079-0 and EN 60079-11. Please observe the maximum admissible electrical values.

After connection to other circuits the sensor may no longer be used in Exi installations. When interconnected to (associated) electrical equipment, it is required to perform the "Proof of intrinsic safety" (EN60079-14).

Installation and mounting instructions

Avoid static charging of cables and plastic devices. Please only clean the device with a damp cloth. Do not install the device in a dust flow and avoid build-up of dust deposits on the device.

If the devices and the cable could be subject to mechanical damage, they must be protected accordingly. They must also be shielded against strong electro-magnetic fields.

The pin configuration and the electrical specifications can be taken from the device marking or the technical data sheet.

In order to avoid contamination of the device, please remove possible blanking plugs of the cable glands or connectors only shortly before inserting the cable or opening the cable socket.

Service/Maintenance

Repairs are not possible. The approval expires if the device is repaired or modified by a person other than the manufacturer. The most important data from the approval are listed.